



CONFIGURATION GUIDE

BHFITNESS

BASIC MODULES



MDA1
SIMPLE
COLUMN



MDA2
DOUBLE
COLUMN



MDA3
RACK COLUMN



MDB1
SIMPLE
SPALDIER



MDB2
DOUBLE
SPALDIER



MDC
CORNER
MODULE



MDD
BRIDGE
MODULE



MDE
HANDLE
MODULE



MDF
FLAT LADDER
MODULE



MDG
UP & DOWN
LADDER
MODULE



MDH
HALF LADDER
MODULE



MAGSYS-ACCP
CLAMP ACCESSORY



MAGSYS-ACS1
SHELF ACCESSORY



MAGSYS-ACS2
SHELF ACCESSORY



MAGSYS-ACS3
SHELF ACCESSORY



MAGSYS-ACS4
SHELF ACCESSORY



MAGSYS-ACLB
LAT BAR ACCESSORY



MAGSYS-ACLM
LAND MINE ACCESSORY



MAGSYS-ACPU
PULL-UP ACCESSORY



MAGSYS-ACAD
DIP STATION
ACCESSORY*




MAGSYS-ACAP
STEP ACCESSORY*







* Can only be placed in rack column module



EXAMPLE OF BASIC CONFIGURATION



MAGSYS
MAIN MEASURES



MAGSYS

CONFIGURATIONS



SIMPLE

MAGSYS-S1

MAGSYS-S2

MAGSYS-S3

MAGSYS-S4

MAGSYS-S5

DOUBLE

MAGSYS-D1

2			1			1				
3			2			2				
4			3			3				
5			4			4				
6			5			5				
	2			1		2				

MAGSYS

CONFIGURATIONS



DOUBLE

MAGSYS-D2

MAGSYS-D2B

CORNER

MAGSYS-C1


MAGSYS-C2

MAGSYS-C5

BRIDGE

MAGSYS-DR

	3			2		4				
	4			2		2		1		
2			2		1					
3			3		1	1				
6			6		1	4				
	2	1		1		1		1		1



4			2				1	1	1	
2	2			2		1	1	1	1	
	4			2		2	1	1	1	
	6			3		2	2	2	2	
5			3			1	1	1	1	
4	2		3	1		3	1	1	1	

MAGSYS

CONFIGURATIONS



2	2	1	1	1		3	2	1	1	1
	2	1		1			1	1	1	1
		2					1	1	1	2